PARTNER

EM-220

User Manual

Copyright

This publication, including all photographs, illustrations and software, is protected under international copyright laws, with all rights reserved. Neither this manual, nor any of the material contained herein, may be reproduced without written consent of the author.

Disclaimer

The information in this document is subject to change without notice. The manufacturer makes no representations or warranties with respect to the contents hereof and specifically disclaims any implied warranties of merchantability or fitness for any particular purpose. The manufacturer reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation of the manufacturer to notify any person of such revision or changes.

Trademark recognition

All product names used in this manual are the properties of their respective owners and are acknowledged.

Federal Communications Commission (FCC)

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and the receiver.

Connect the equipment onto an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Shielded interconnect cables and a shielded AC power cable must be employed with this equipment to ensure compliance with the pertinent RF emission limits governing this device. Changes or modifications not expressly approved by the system's manufacturer could void the user's authority to operate the equipment.

WARNING

This is a class A product. In a domestic environment this product may causeradio interference in which case the user may be required to take adequate measures.

Declaration of conformity

This device complies with part 15 of the FCC rules. Operation is subject to the following conditions:

This device may not cause harmful interference, and

This device must accept any interference received, including interference that may cause undesired operation.

About this manual

This manual is intended for system administrators who are familiar with setting up a new system and installing an operating system.

The manual consists of the following sections:

Chapter 1 Getting Started:	This section covers unpacking and checking the package contents, identifying components, installing the battery pack, charging the battery and powering on.
Chapter 2 BIOS Setup Utility:	The BIOS chapter provides information on navigating and changing settings in the BIOS Setup Utility.
Chapter 3 Upgrading Components:	This section provides information on upgrading components.
Appendix:	The appendix covers troubleshooting, information on having the EM-220 serviced, and technical specifications.

Safety information

Before installing and using the EM-220, take note of the following precautions:

- Read all instructions carefully.
- SAR compliance for body-worn operations is restricted which provide at least 2 cm separation between the device and the user's body
- Do not place the unit on an unstable surface, cart, or stand.
- Do not block the slots and opening on the unit, which are provided for ventilation.
- Do not push objects in the ventilation slots as they may touch high voltage components and result in shock and damage to the components.
- Do not place anything on the power cord. Place the power cord where it will not be in the way of foot traffic.
- Follow all warnings and cautions in this manual and on the unit case.
- When replacing parts, ensure that your service technician uses parts specified by the manufacturer.
- Avoid using the system near water, in direct sunlight, or near a heating device.
- Never throw the battery into a fire or put it near a fire.

WARNING

Warning! Batteries may explode if not handled properly. Do not disassemble or dispose of them in fire. Keep them away from children. Follow local regulations when disposing of used batteries.

警告

不正確地更換電池會有爆炸的危險。僅可更換為廠商建議的相同電池或相同型式電池。請依據廠商說明書棄置電池。

注意

用错误型号电池更换会有爆炸危险务必按照说明处置用完的电池。

TABLE OF CONTENTS

CHAPTER 1 GETTING STARTED 1

Unpacking the machine 1
Checking the package contents 2
Identifying components 3
Installing the battery pack 8
Charging the battery pack 9
Powering on 10

CHAPTER 2 BIOS SETUP 11

About the Setup Utility 11
Entering the Setup Utility 12
BIOS navigation keys 12
Using BIOS 13
Main Screen 14
Advanced Settings 15
IDE Configuration 16
General ACPI Configuration 17
USB Configuration 18
Boot Settings 19
Boot Settings Configuration 20
Boot Device Priority 21
Hard Disk Drives 22
Network Drives 23
Security Settings 24
Chipset Settings 25
North Bridge Chipset Configuration 26
Exit Menu 27

CHAPTER 3 UPGRADING COMPONENTS 29

Safety and precautions 29
Before you begin 30
Upgrading the hard drive 31
Upgrading the memory module 33
Upgrading the Mini-PCIE card 34

APPENDIX 37

Troubleshooting 37

Tips for Troubleshooting.....37
General Problems 38
Having the EM-220 Serviced 39
Specification.....40

Revision history

Version 1.0, August 2011

CHAPTER 1
GETTING STARTED

This chapter describes the procedures from unpacking the EM-220, to powering it on. The following topics are described.

- Unpacking the machine on page 1
- Checking the package contents on page 2
- Identifying components on page 3
- Installing the battery pack on page 8
- Charging the battery pack on page 9
- “Powering on” on page 10

Unpacking the machine

The machine and cable accessories are packed in a cardboard carton with foam padding for protection during shipping.



Figure 1.1 Unpacking the machine

Carefully unpack the machine and keep the packing materials. If you need to ship it in the future, repack it as shown in Figure 1.1.

Checking the package contents

After you unpack the device, check that the following items are included.



EM-220



Metal Stylus



Battery



Protection pack



Driver CD with drivers and the user manual PDF file.

Quick Start Guide



AC adapter



Power cord

If any item is missing or appears damaged, contact your dealer immediately.

Identifying components

This section describes the parts and connectors on the machine.

Front view



Figure 1.2 Front view

Component	Description
1	Power indicator
2	Battery charging indicator
3	HDD status indicator
4	WiFi On/ Off indicator
5	Bluetooth On/ Off indicator
6	3.5G LAN On/Off indicator (optional)
7	Built-in Microphone
8	Camera (optional)
9	10.1-inch touch panel

Left view



Figure 1.3 Left view

Component	Description
1	5-in-1 media card slot
2	Express card slot
3	USB port
4	Power button
5	RJ45 LAN jack
6	DC IN

Right view



Figure 1.4 Right view

Component	Description
1	VGA port
2	Ventilation hole
3	USB port
4	Headphone jack
5	Microphone jack

Rear view



Figure 1.5 Rear view

Component	Description
1	Speaker
2	Battery pack
3	Charger pin: connect to a cradle for charging the battery.

IMPORTANT

Do not short-circuit these 2 charger pins. A short-circuit may cause damage to the machine and present risks for electric shock or fire.

Bottom view



Figure 1.6 Bottom view

Component	Description
1	Mounting hole
2	Camera (optional)
3	Battery lock switch
4	Memory, WiFi module and 3.5G LAN module (optional) slots
5	Battery pack
6	HDD compartment
7	Battery release latch

Installing the battery pack

1. Overturn the EM-220 so that the bottom is facing up toward you, as shown in the right. Slide the battery release latch to the unlock position.



2. Align EM-220 battery compartment pins to the battery connector. Slightly slide and press the battery pack into the compartment until the battery lock switch is bounced back.



3. As shown in the right, slide the battery release latch to the lock position.



Charging the battery pack

Plug the AC adapter power cord into an electrical outlet, then connect the DC plug of the adapter cable to the EM-220. It takes approximately 2–4 hours to fully charge the battery for the first time. Subsequent charges might take longer.



NOTE

Charge the battery within a temperature range 0˚C to 45˚C.

IMPORTANT

To protect and prolong the life of the battery, do not charge it for 24 hours or longer at a time.

IMPORTANT

Please make sure to perform 3 complete full charge and discharge cycles to get optimal battery capacity. Failure to comply will result in shorter battery lifespan.

IMPORTANT

If battery is not used, please store in dry area within a temperature range of -10˚C ~ 20˚C. It is necessary to charge the battery once every 3 months to avoid battery degradation. Battery may become unusable if the above is not respected.

Powering on

The power button located on the left side of the EM-220, press the power button the turn it on.



NOTE

To force power off , long press the power button for 4~5 seconds.

CHAPTER 2
BIOS SETUP

The primary function of the BIOS (Basic Input and Output System) is to identify and initiate component hardware. The BIOS parameters are stored in non-volatile BIOS memory (CMOS). CMOS contents don't get erased when the computer is turned off. The following topics are described in this chapter.

- About the Setup Utility on page 11
- Main Screen on page 14
- Advanced Settings on page 15
- Boot Settings on page 19
- Security Settings on page 24
- Chipset Settings on page 25
- Exit Menu on page 27

About the Setup Utility

The BIOS Setup Utility enables you to configure the following items:

- Hard drives, diskette drives, and peripherals
- Video display type and display options
- Password protection from unauthorized use
- Power management features

This Setup Utility should be used for the following:

- When changing the system configuration
- When a configuration error is detected and you are prompted to make changes to the Setup Utility
- When trying to resolve IRQ conflicts
- When making changes to the Power Management configuration
- When changing the User or Supervisor password

Entering the Setup Utility

When you power on the system, BIOS enters the Power-On Self Test (POST) routines. POST is a series of built-in diagnostics performed by the BIOS. After the POST routines are completed, the following message appears:

Press DEL to run Setup

Press the delete key <Delete> to access the BIOS Setup Utility:



Figure 2.1 Main BIOS screen

BIOS navigation keys

The BIOS navigation keys are listed below.

Key	Function
← →	Select screens
↑ ↓	Select items
+ –	Modifies the selected field's values
Enter	Go to sub screen
F1	Displays the general help
F10	Saves the current configuration and exits Setup
Esc	Exits the current screen

Using BIOS

When you start the Setup Utility, the main screen appears. The main screen of the Setup Utility displays a list of the options that are available. A highlight indicates which option is currently selected. Use the cursor arrow keys to move the highlight to other options. When an option is highlighted, execute the option by pressing <Enter>.

Some options lead to pop-up dialog boxes that prompt you to verify that you wish to execute that option. Other options lead to dialog boxes that prompt you for information.

Some options (marked with a triangle ►) lead to sub screens that enable you to change the values for the option. Use the cursor arrow keys to scroll through the items in the sub screen.

Main Screen

This screen includes System BIOS Information, Processor, System memory and displays the System Time and System Date.



Figure 2.2 Main Screen

System Overview

This screen displays System BIOS Information, Processor, System memory, System Time and System Date.

System Time/ System Date

The System Time and System Date items show the current date and time held by the machine. If you are running a Windows OS, these items are automatically updated whenever you make changes to the Windows Time and Date Properties utility.

Advanced Settings

This setup screen includes sub-menus for IDE Configuration, USB Configuration, ACPI Configurations, MPS Configurations, Super IO Configurations and Hardware Health Configuration.



Figure 2.3 Advanced Settings Screen

ALL ON/ALL OFF/Customize

This item allows users to on/off expansion modules.

[All On] Enable BT, WLAN, WWAN, G Sensor, Front Camera and Rear Camera.

[All Off] Disable BT, WLAN, WWAN, G Sensor, Front Camera and Rear Camera.

[Customize] Set each module separately.

Touch Panel

This feature allows users to select the type for touch panel.

IDE Configuration



Figure 2.4 IDE Configuration sub-menu

ATA/IDE Configuration

This item allows users to specific the integrated IDE controller.

[Disabled] disables the integrated IDE controller.

[Compatible] enables up to two IDE channels for operating systems requiring legacy IDE operation.

[Enhanced] enables all SATA and PATA resources.

General ACPI Configuration



Figure 2.5 General ACPI Configuration sub-menu

Suspend mode

Use this item to define how the system suspends. In the default, S1(POS), the suspend mode is equivalent to a software power down. If you select S3(STR), the suspend mode is a suspend to RAM - the system shuts down with the exception of a refresh current to the system memory.

Wake-On-Lan (WOL)

This feature allows the system to be woken up by a network message.

USB Configuration



Figure 2.6 USB Configuration sub-menu

USB 2.0 Controller Mode

This item allows you to specific the USB 2.0 controller in HiSpeed (480Mbps) or Full Speed (12Mbps).

Boot Settings

This screen allow you to configure the boot options.



Figure 2.7 Boot Settings screen

Boot Settings Configuration


BIOS SETUP UTILITY
Boot
Boot Settings Configuration
Quick Boot [Enabled]
Quiet Boot [Disabled]
Bootup Num-Lock [On]
Allows BIOS to skip certain tests while booting. This will decrease the time needed to boot the system.
↔ Select Screen
↑↓ Select Item
+- Change Option
F1 General Help
F10 Save and Exit
ESC Exit

Figure 2.8 Boot Settings Configuration sub-menu

Quick Boot
Enabling this setting will cause the BIOS power-on self test routine to skip some of its tests during booting for faster system boot.

Quiet Boot
When enabled, system will boot without message. In contrast, when disabled, system will boot in text mode.

Bootup Num-Lock
This setting is to set the Num Lock status when the system is powered on. Setting to [On] will turn on the Num Lock key when the system is powered on. Setting to [Off] will allow users to use the arrow keys on the numeric keypad.

Boot Device Priority

Use this screen to specify the order in which the system checks for the device to boot from.



Figure 2.9 Boot Device Priority sub-menu

1st Boot Device
2nd Boot Device

Set the boot device options to determine the sequence in which the computer checks which device to boot from.

Hard Disk Drives

Use this screen to specify the boot sequence from hard disk drives.



Figure 2.10 Hard Disk Drives sub-menu

1st Drive

Use this item to view the hard disk drives in the system.

Network Drives

Use this screen to specify the boot sequence from network drives.



Figure 2.11 Network Drives sub-menu

1st Drive

Use this item to view the network drives in the system.

Security Settings

This screen allows you to configure the system security settings.



Figure 2.12 Security Settings screen

Supervisor/ User Password

Indicates whether a password has been set. If the password has been installed, *Installed* displays. If not, *Not Installed* displays.

Set Supervisor Password

This item is used to establish password protection when entering the BIOS setup.

Set User Password

This item is used to establish password protection when entering the BIOS setup but some menu items will be unavailable. A supervisor password must be set before a user password can be used.

Boot Sector Virus Protection

This feature can prevent modifications to the boot sector.

Chipset Settings

This screen allow you to configure the North Bridge and South Bridge chipset options.


BIOS SETUP UTILITY
Main Advanced Boot Security Chipset Exit
Advanced Chipset Settings
WARNING: Setting wrong values in below sections
may cause system to malfunction.
▶ North Bridge Configuration
Configure North Bridge features.
↔ Select Screen
↑↓ Select Item
Enter Go to Sub Screen
F1 General Help
F10 Save and Exit
ESC Exit

Figure 2.13 Chipset Settings screen

North Bridge Chipset Configuration


BIOS SETUP UTILITY
Chipset
North Bridge Chipset Configuration
Internal Graphics Mode Select [Enabled, 8MB]
Boot Display Device [CRT + LVDS]
Flat Panel Type [800 X 600]
LVDS Backlight Control [100%]
Select the amount of system memory used by the Internal graphics device.
↔ Select Screen
↑↓ Select Item
+- Change Option
F1 General Help
F10 Save and Exit
ESC Exit

Figure 2.14 North Bridge Chipset Configuration sub-menu

Internal Graphics Mode Select
This feature controls the amount of system memory that is allocated to the integrated graphic process when the system boot up.

Boot Display Device
If you connect an external display to this machine, you can use this setting to turn off the LCD and only use the external display. To use dual displays this must be set to CRT+LVDS.

Flat Panel Type
This item allows you to select the type of Flat Panel Monitor.

LVDS Backlight Control
This feature allows you to adjust the backlight of the LVDS.

Exit Menu

This screen allows you to load the optimal default values, and save or discard changes.



Figure 2.15 Exit Menu screen

Exit Saving Changes

Highlight this item and press <Enter> to save the changes that you have made in the Setup Utility and exit the Setup Utility. When the dialog box appears, press <OK> to save and exit, or press <Cancel> to return to the menu.

Exit Discarding Changes

Highlight this item and press <Enter> to discard any changes that you have made in the Setup Utility and exit. When the dialog box appears, press <OK> to discard changes and exit, or press <Cancel> to return to the menu.

NOTE

If you have made settings that you do not want to save, use the "Exit Discarding Charges" item and press OK to discard any changes you have made.

Load Optimal Defaults

This option opens a dialog box that lets you load optimized defaults for all appropriate items in the Setup Utility. The optimized defaults place demands on the system that may be greater than the performance level of the components, such as the CPU and the memory. You can cause fatal errors or instability if you load the optimized defaults when the hardware does not support them. If you only want to load setup defaults for a specific option, select and display that option, and then press <F9>.

Follow these instructions to load the optimized defaults:

1. From the Exit screen, scroll to Load Optimized Defaults.
2. Press <Enter> to open the Load Optimized Defaults screen.
3. Select <Ok>.
4. Press <Enter> to load the defaults.

Discard Changes

Highlight this item and press <Enter> to discard any changes that you have made in the Setup Utility. When the dialog box appears, press <OK> to discard changes and exit, or press <Cancel> to return to the menu.

CHAPTER 3
UPGRADING COMPONENTS

This chapter describes how to upgrade components for the EM-220. The following topics are described.

- Safety and precautions on page 29
- Before you begin on page 30
- Upgrading the hard drive on page 31
- Upgrading the memory module on page 33
- Upgrading the Mini-PCIE card on page 34

Safety and precautions

Computer components and electronic circuit boards can be damaged by discharges of static electricity. Working on computers that are still connected to a power supply can be extremely dangerous. Follow these guidelines to avoid damage to the computer or injury to yourself.

- Always disconnect the unit from the power outlet.
- Leave all components inside the static-proof packaging that they ship with until they are ready for installation.
- After replacing optional devices, make sure all screws, springs, or other small parts are in place and are not left loose inside the case. Metallic parts or metal flakes can cause electrical shorts.

CAUTION

Only qualified personnel should perform repairs on the machine. Damage due to unauthorized servicing is not covered by the warranty. If you are not confident of installing a hard drive, memory card or LAN card, we recommend that you refer the job to qualified personnel.

WARNING

If the LCD breaks and fluid gets onto your hands or into your eyes, immediately wash with water and seek medical attention.

WARNING

The inverter card has high voltage. Do not touch the inverter card while power is connected to the machine. Unplug the power cord before attempting to replace any part.

CAUTION

To prevent static damage to components, wear a grounded wrist strap. Alternatively, discharge any static electricity by touching the bare metal chassis of the unit case, or the bare metal body of any other grounded appliance.

CAUTION

Hold electronic circuit boards by the edges only. Do not touch the components on the board unless it is necessary to do so. Do not flex or stress the circuit board. Do not hold components such as a processor by its pins; hold it by the edges.

Before you begin

Make sure you have a stable, clean working environment. Dust and dirt can get into components and may cause malfunction. Adequate lighting and proper tools can prevent you from accidentally damaging the internal components.

Most of the electrical and mechanical connections can be disconnected by using your fingers. It is recommended that you do not use needle-nosed pliers to disconnect connectors as these can damage the soft metal or plastic parts of the connectors.

CAUTION

To prevent scratching the case of the machine, make sure the worktop surface is clean and flat.

Upgrading the hard drive

Refer to the following to remove and replace the hard drive.

1. Turn off the EM-220. 2. Disconnect the AC adapter cable. 3. Overturn the EM-220. 4. Remove the two screws as shown in the right.	
5. Open and remove the hard drive compartment cover.	
6. Slide the hard drive to disconnect.	

7. Remove the hard drive.	
8. Remove the four screws, then remove the hard drive out from the tray.	

To replace the hard drive, reverse the above procedure.

Upgrading the memory module

Refer to the following to remove and replace the memory.

1. Turn off the EM-220. 2. Disconnect the AC adapter cable. 3. Overturn the EM-220. 4. Remove the two screws as shown in the right.	
5. Open and remove the memory module compartment cover.	
6. Locate the memory module, as shown in the right.	

7. Pop out the two silver latches holding the memory module into place. The module pops up. Grasp the outer edges of the memory module with thumb and forefinger, and then gently remove it.	

To replace the memory module, reverse the above procedure.

Upgrading the Mini-PCIE card

Refer to the following to remove and replace the PCIE card.

1. Turn off the EM-220. 2. Disconnect the AC adapter cable. 3. Overturn the EM-220. 4. Remove the two screws as shown in the right.	
5. Open and remove the Mini-PCIE card compartment cover.	

6. Locate the Mini-PCIE card, as shown in the right.	
7. Remove the screw on the Mini-PCIE card, Mini-PCIE will pop up 45 degree. 8. When it pops up, gently remove it.	

To replace the Mini-PCIE card, reverse the above procedure.

This appendix describes locating and solving problems that you may encounter while using the EM-220.

Troubleshooting

Often after time spent troubleshooting, the problem is traced to something as simple as a loose connection. Check the following before proceeding to the problem-specific solutions.

Tips for Troubleshooting

In each problem-specific section, try the steps in the order suggested. This may help you to solve the problem more quickly. Try to pin point the problem and thus avoid replacing non-defective parts. For example, if you replace batteries and the problem remains, put the original batteries back and go to the next step.

Keep a record of the steps you take when troubleshooting: The information may be useful when calling for technical support or for passing on to service personnel.

- Use some other electrical device to confirm that the electrical outlet is working.
- Ensure all connections are securely attached.

General Problems

Refer to the following general problems you may encounter.

PROBLEM	SOLUTION
The display screen is dark.	Make sure that the EM-220 is not in suspend mode.
An incorrect date and time are displayed.	Set the date and time in BIOS or Operation System.
Cannot be turned off after crash.	Long press the power button for 4 seconds to force shutdown.
Cannot be powered on	Connect the AC adapter, if it can be powered on, there is insufficient battery power. If it still unable to be powered on after charging, please have the EM-220 serviced.

Having the EM-220 Serviced

If you are unable to solve the problem, you should have the terminal serviced. Pack the terminal in the original carton. (See “Unpacking the EM-220” on page 1.) Include a description of the problem and a checklist of the steps you took when trying to fix the problem. The information may be useful to the service personnel. Return the terminal to the place you purchased it.

Specification

Processor	Intel® ATOM N455 1.66GHz
LCD	10.1” Active TFT color LCD, resolution 1024 x 600, or 1366 x768(option)
Touch	4-wire Resistive touch
Memory	DDR3 1GB Standard, Maximum 2 GB (1 x DDR3 SO-DIMM Slots)
Ethernet	On board LAN chip 10/100/1000 BASE-T Gigabit Ethernet
Storage	2.5” type SATA HDD
I/O Interface	1 * DB-15 VGA port
	1 * RJ-45 LAN port
	2 * Audio ports (1 * Line-out , 1 * MIC-in)
	3 * USB 2.0
	1 * 5 in 1 card reader slot, support SD,MMC,MS,MS pro , XD
	1 * express34 slot
	1* SIMM slot
Expansion Options	2 * Mini PCI-e, Support wireless LAN and 3G Module(option)
Battery life	3 hours (estimated)
Operation System	Windows 7, Windows XP, XPe, Linux (ubuntu, Fedora) , WEPOS, POSReady
Optional Peripherals	POS Base
	Charging Base
	EM-220 Jacket with MSR , RFID or Barcode scanner modules (1D or 2D)
	VESA mount (75x75mm, 100x100mm)
Power Supply	AC100~240V/DC12V, 36 watt power adaptor
Dimensions	Physical:189mm (W) x268mm (H) x 25.7mm (T)
Weight	Appox.1160g
Operating Temp	0°C ~ +40°C

* specification subject to change without prior notice